

PRODUCT INFORMATION



Food Processing Machines



Burger Former – Bully1000-230 model

- Automated production of patties, fish cakes or similar products
- Incl. single forming drum for patties with diameter 130 mm, max. height 32 mm
- With single forming drum production of up to 1,300 pieces per hour
- Easy adjustment of the cutting height with the help of an adjustment and locking screw at the forming drum
- Peraluman castings, other parts stainless steel
- Cleaning the housing with a water hose (no high pressure!), housing IP65, switch unit IP69
- Aluminum mixing paddle
- Continuous movement of the product with the help of the mixing paddle for uniform mixing of the mass to be processed
- Incl. scraper for the forming drum for cleaning during operation
- Easy disassembly of mixing paddle, hopper, scraper, conveyor belt, forming drum and accessories for easy cleaning
- Removable parts are dishwasher safe
- Magnetic sensors to control the closed lid, the closed protective cap and built-in forming drum for maximum security
- Hopper volume: 16 Liter
- Conveyor belt length: 390 mm

Options:

- Release film dispenser for separating films size 114 x 114 mm and 135 x 135 mm (not retrofittable)
- Stainless steel mixing paddle
- Extended conveyor belt: 900 mm
- Cleaning wire on the conveyor belt (not retrofittable)
- Pneumatic scraper (not retrofittable)
- Foot pedal as a pulse switch for manual operation (not retrofittable)
- Mobile base frame (not retrofittable)
- More single, double, triple, and quadruple as well as special forming drums, max. height 32 mm

Technical Specifications

Model	Bully1000-230
Art. No.	4352
Dimensions (WxDxH)	518 x 579 x 607 mm
Dead weight	57 kg
Power rating	0.55 kW
Type of current	230 V

Technical modifications might be due to technical improvements.