

# PRODUCT INFORMATION



## Electronic Wall Scales



**More safety:** locking the raised weighing table by a locking bolt

Folded: only 125 mm deep

## Wall Scales with fence bar – TerrexL + STAN07 (approved available)

- Foldable weighing table and fence bar made of polished stainless steel – IP67
  - Space saving: depth only 125mm, when hinged
  - **More safety:** locking the raised weighing table by a locking bolt
  - Ideal for weighing when inspecting incoming goods – even in the smallest spaces
  - Base frame in stainless steel
  - Wall bracket galvanised
  - Aluminum weighing cell with polished stainless steel covering
  - Completely mounted with digital indicator STAN07 in stainless steel housing – IP65
  - Functions tested with 3 m measuring cable
  - Large backlit LCD, height of digits 25 mm
  - Functions: Weighing, taring, counting, total, free programmable minimum and peak values for check weighing with optical and acoustical support
  - Lights function: programmable change of colour of backlight in dependence of goal attainment
  - 100 memory positions each for check weighing weights, reference weights and check weighing in the counting range
  - RS232 interface for connecting to a PC or printer
  - Mains operation (100-240V/50-60Hz; mains adapter integrated with 2 m mains cable)
  - Indicator for placing on a table or for wall mounting (including wall mounting bracket for the indicator)
- Options:**
- Stainless steel load cell IP68 – TerrexL-IP+STAN07
- Prerequisite is the load-bearing capacity of the wall!**

**Note:** Please order of approval with the scale, subsequent approval not possible!

Technical Specifications						
Model	Art. no.	Weighing platform mm	Dimensions mm	Capacity	Graduation	Dead weight
TerrexL-60+STAN07	2385-60	550 x 458	550 x 529 x 363	60 kg	20 g	30 kg
TerrexL-150+STAN07	2385-150	550 x 458	550 x 529 x 363	150 kg	50 g	30 kg
Technical specifications might be due to further developments.						