

PRODUCT INFORMATION



Electronic Industrial Scale



Stainless Steel Floor Scale – BW2-NIRO+STAN07 series (CE approved available)

- For floor installation: can be easily accessed with a forklift or pallet truck
 - Robust, flat, and level design with a height of approximately 16 cm ensures stability and reliability
 - High-quality stainless steel construction, making it particularly durable and corrosion-resistant
 - Height-adjustable feet to accommodate uneven surfaces
 - Overload protection to prevent damage from excessive strain
 - Unscrewable weighing platform
 - Load cells made of nickel-plated steel IP67
 - Compact junction box made of stainless steel IP65
 - Measurement cable separation for easy disassembly of the digital display
 - Quality and precision from German manufacturing
 - Completely mounted and functions tested with 8 m connection cable with digital indicator STAN07 in stainless steel
 - Large backlit LCD-Display, height of digits 25 mm
 - Weighing, taring, counting, total, freely programmable minimum and peak values with optical and acoustical support
 - Lights function: programmable change of colour of backlight in dependence of goal attainment
 - 100 memory positions each for check-weighing weights, reference weights and check weighing in the counting range
 - RS232 interface for connecting to a PC or printer
 - Mains operation (100-240V/50-60Hz)
 - Indicator for placing on a table or for wall mounting (including wall mounting bracket for the indicator)
- Options:**
- Stand for Indicator ADE STAN07 in RAL9005
 - Lithium-Ion rechargeable battery for indicator STAN07

Note: If approved version (models –e) is needed, please order approval with the scale.

Later approval isn't possible!

For CE approval outside Germany, please be sure to provide the postal code of the installation location.

Technical Specifications

Model	Weighing platform mm	Art. No.	Capacity kg	Graduation g
BW2-Niro-1000x800-300+STAN07	1000 x 800	1367-300	300	100
BW2-Niro-1000x800-600+STAN07	1000 x 800	1367-600	600	200
BW2-Niro-1250x1000-600+STAN07	1250 x 1000	1368-600	600	200
BW2-Niro-1250x1000-1500+STAN07	1250 x 1000	1368-1500	1,500	500
BW2-Niro-1500x1250-1500+STAN07	1500 x 1250	1369-1500	1,500	500
BW2-Niro-1500x1250-3000+STAN07	1500 x 1250	1369-3000	3,000	1,000

Technical specifications might be due to further developments.