

PRODUCT INFORMATION



Electronic Industrial Scale



Optional with base frame for use as a floor-mounted scale

Hinged Stainless Steel Floor Scale – BW3-NIRO+STAN07 series (CE approved available)

- Robust and flat design ensures stability and reliability
- High-quality stainless steel construction, making it particularly durable and corrosion-resistant
- Foldable load plate with powerful specially coated gas springs for effortless manual opening
- Overload protection to prevent damage from excessive strain
- Load cells made of stainless steel IP68
- Compact junction box made of stainless steel IP65
- Measurement cable separation for easy disassembly of the digital display
- Quality and precision from German manufacturing
- Completely mounted and functions tested with 8 m connection cable with digital indicator STAN07 in stainless steel housing – IP65
- Large backlit LCD-Display, height of digits 25 mm
- Weighing, taring, counting, total, freely programmable minimum and peak values with optical and acoustical support
- Lights function: programmable change of colour of backlight in dependence of goal attainment
- 100 memory positions each for check-weighing weights, reference weights and check weighing in the counting range
- RS232 interface for connecting to a PC or printer
- Mains operation (100-240V/50-60Hz)
- Indicator for placing on a table or for wall mounting (including wall mounting bracket for the indicator)

Options:

- Base frame for use as a floor-mounted scale
- Stand for Indicator ADE STAN07 in RAL9005

Note: If approved version (models –e) is needed, please order approval with the scale.
Later approval isn't possible!
For CE approval outside Germany, please be sure to provide the postal code of the installation location.

Technical Specifications

Model	Weighing platform mm	Art. No.	Capacity kg	Graduation g
BW3-Niro-1000x800-300+STAN07	1000 x 800	1387-300	300	100
BW3-Niro-1000x800-600+STAN07	1000 x 800	1387-600	600	200
BW3-Niro-1250x1000-600+STAN07	1250 x 1000	1388-600	600	200
BW3-Niro-1250x1000-1500+STAN07	1250 x 1000	1388-1500	1,500	500
BW3-Niro-1500x1250-600+STAN07	1500 x 1250	1389-600	600	200
BW3-Niro-1500x1250-1500+STAN07	1500 x 1250	1389-1500	1,500	500

Technical modifications might be due to further developments.