

PRODUCT INFORMATION



Electronic Industrial Scale



Counting System – ZS2-PWL series

- Counting system consisting of a counting scale as reference scale with 3 kg maximum load and a pallet scale as quantity scale
 - Weighing, Taring, Counting, Summing
 - 10-key pad for entering reference weight, reference quantity, and tare
 - User guidance and reference weight optimization
 - Input of target price count or target weight
 - Memory slots for 99 items with reference weight, additional text, and tare
- Reference scale:
- Robust industrial design in stable plastic housing
 - Three LCD displays for weight indication, reference weight, and total piece count, digit height 20 mm
 - Weighing surface made of high-quality and stainless steel
 - Automatic shut-off in battery operation
 - Mains and battery operation, battery life up to 80 hours (including battery)
 - Second scale connection with quantity scale PWL for setting up a high-resolution counting system
- Quantity scale:
- Pallet scale in lacquered version
 - Optimized for Euro pallets
 - Can be stored in an upright position
 - High mobility for easy transport due to handle and integrated castors

Technical Specifications

Model	Art. No.	Weighing platform Reference scale / Quantity scale	Capacity Reference scale / Quantity scale	Graduation Reference scale / Quantity scale
ZS2-PWL-600	2812-600	295 x 220 840 x 1360 x 80	3 kg 600 kg	0,1 g 20 g
ZS2-PWL-1500	2812-1500	295 x 220 840 x 1360 x 80	3 kg 1500 kg	0,1 g 50 g
ZS2-PWL-3000	2812-3000	295 x 220 840 x 1360 x 80	3 kg 3000 kg	0,1 g 100 g

Technical modifications might be due to further developments.