

Electronic Counting Scale



Counting Scale – Series ZW50

- 3 LCD displays for weight, unit weight, and number of parts, height of digits 20mm
- 10-number keypad to enter the reference weight, reference number of parts and the tare weight
- Operator guidance and reference weight optimization
- Memory for 99 items (PLU) for reference weight, text description and tare
- Weighing, Taring, Counting, Summarizing
- Entering of target value or target
- Heavy-duty industrial design
- Automatic shut-off with rechargeable battery
- Weighing platform in stainless steel
- Mains and rechargeable batteries: 230V AC, rechargeable batteries with approx. 80 h working hour
- With interface for second scale for high-resolution counting system, e. g. with ADE platform scale series VSL or palett scale series PWL

Technical Specifications

Model	ZW50-3	ZW50-6	ZW50-15	ZW50-30
Art. No.	2850-3	2850-6	2850-15	2850-30
Capacity	3 kg	6 kg	15 kg	30 kg
Graduation	0,1 g	0,2 g	0,5 g	1 g
Min. unit weight/ Min. placing parts	min. 0,05g/ 50 pieces	min. 0,1g / 25 pieces	min. 0,2g / 25 pieces	min. 0,5g / 15 pieces
Weighing platform	295 x 220 mm			
Dimensions (WxDxH)	315 x 330 x 125 mm			
Dead weight	3.8 kg			

Technical specifications might be due to further developments.