

PRODUCT INFORMATION



Electronic Wall Scales



More safety: locking the raised weighing table by a locking bolt



Folded: only 125 mm deep

Wall Scales with fence bar – TerrexL-IP + STAN07 (approved available)

- Foldable weighing table and fence bar made of polished stainless steel – IP67
 - Space saving: depth only 125mm, when hinged
 - **More safety:** locking the raised weighing table by a locking bolt
 - Ideal for weighing in a harsh working environment – even in the smallest spaces
 - Base frame in stainless steel
 - Wall bracket galvanised
 - Stainless steel load cell IP68
 - Completely mounted with digital indicator STAN07 in stainless steel housing – IP65
 - Functions tested with 3 m measuring cable
 - Large backlit LCD, height of digits 25 mm
 - Functions: Weighing, taring, counting, total, free programmable minimum and peak values for check weighing with optical and acoustical support
 - Lights function: programmable change of colour of backlight in dependence of goal attainment
 - 100 memory positions each for check weighing weights, reference weights and check weighing in the counting range
 - RS232 interface for connecting to a PC or printer
 - Mains operation (100-240V/50-60Hz; mains adapter integrated with 2 m mains cable)
 - Indicator for placing on a table or for wall mounting (including wall mounting bracket for the indicator)
- Options:**
- Aluminum weighing cell with polished stainless steel covering – TerrexL+STAN07
- Prerequisite is the load-bearing capacity of the wall!**

Note: Please order of approval with the scale, subsequent approval not possible!

Technical Specifications						
Model	Art. no.	Weighing platform mm	Dimensions mm	Capacity	Graduation	Dead weight
TerrexL-150-IP+STAN07	2386-150	550 x 458	550 x 529 x 363	150 kg	50 g	30 kg
Technical specifications might be due to further developments.						