## PRODUCT INFORMATION



## Gravity Feed Slicers with automatic Transmission



## Automatic Gravity Feed Slicer – AUTOMATIC-XL-230

- Optimal processing due to steeply slope of the carriage and automatic transmission of carriage
- Automatic operation of the carriage in ten speed levels with 20-50 movements per minute, also reversible in manual operation
- Three stroke lengths adjustable
- Counting device with auto-stop-function
- Solid housing and carriage in anodized aluminum
- Powerful motor
- Switch unit IP69
- Housing IP54

- Multifunctional blade of the latest generation: 2-level profile and hard-chrome plated surface finish for improved non-stick effect (Teflon blade no longer required for cutting cheese)
- Continuously adjustable slice thickness: 0 15 mm
- Easy cleaning thanks to foldable carriage
- Includes guide rail for product fixation
- Delivery includes a sharpening tool
- Suitable for intended continuous operation

## Option

Cut protection glove

Technical Specifications	
Model	Automatic-XL-230
Art. No.	4340
Blade Ø	300 mm
Cutting area	220 x 180 mm
Power rating	0.27 kW
Dimensions (WxDxH)	630 x 668 x 629 mm
Dead weight	41.5 kg
Type of current	230 V
Technical modifications might be due to technical improvements.	