

PRODUCT INFORMATION



Gravity Feed Slicers with automatic Transmission



Automatic Gravity Feed Slicers – AUTOMATIC-L-230

- Optimal processing due to steeply slope of the carriage and automatic transmission of carriage
 - Automatic operation of the carriage up to 40 movements per minute, also reversible in manual operation
 - Solid housing and carriage in anodized aluminum
 - Powerful motor
 - Switch unit IP69
 - Housing IP54
 - Multifunctional blade of the latest generation: 2-level profile and hard-chrome plated surface finish for improved non-stick effect
 - Continuously adjustable slice thickness: 0 – 15 mm
 - Easy cleaning thanks to foldable carriage
 - Includes guide rail for product fixation
 - Delivery includes a sharpening tool
 - Suitable for intended continuous operation
- Option**
- Cut protection glove

Technical Specifications

Model	Automatic-L-230
Art. No.	4339
Blade Ø	300 mm
Cutting area	220 x 180 mm
Power rating	0.27 kW
Dimensions (WxDxH)	630 x 668 x 629 mm
Dead weight	43 kg
Type of current	230 V

Technical modifications might be due to technical improvements.