

PRODUCT INFORMATION



Straight Feed Slicers



Removable carriage
for easy cleaning

Straight Feed Slicers – Series GLORIA

- Reliable vertical slicer for high demands
- Robust housing made of special aluminum alloy – anodised
- Carriage, stop plate and guard made of anodised aluminum
- Extremely robust, wear-resistant and fatigue piezo switch technology for a high number of switching cycles
- Air-cooled motor with extremely quiet drive
- Multifunctional blade of the latest generation: 2-level profile with hard-chrome plated surface finish for improved non-stick effect
- Continuously adjustable slice thickness: 0-13 mm
- Four suction feet for safe standing
- Gentle carriage stop
- Sturdy stainless steel thumb protector
- Viewing slots on the thumb protection for safe operation
- Carriage easy to remove for effortless cleaning
- Product grip with 360° rotation
- Rough product retainer plate for secure hold of the product
- Suitable for intended continuous operation
- Delivery includes sharpening tool

Options

- Blade removal tool for the knife for save purgation
- Cut Protection glove
- Teflon-coating for knives, e. g. for cutting cheese
- Serrated knife for cutting bread

Technical Specifications

Model	Gloria250-230	Gloria250-400	Gloria300-230	Gloria300-400
Blade Ø	250 mm		300 mm	
Cutting area	230 x 195 mm		230 x 215 mm	
Dimensions (WxDxH)	565 x 600 x 375 mm		565 x 600 x 405 mm	
Dead weight	21 kg		23 kg	
Power rating	0.242 kW		0.242 kW	
Type of current	230 V	400 V	230 V	400 V
Art. No.	4026	4056	4027	4057

Technical modifications might be due to technical improvements.