

# PRODUCT INFORMATION

# ADE

## Slicing machines



Large cutting area due to diagonal backwards moving feedplate



## Bread slicing machine – Model Panis250

- Special slicing machine with toothed blade especially for cutting bread
- Two features for large cutting area:
  - Diagonal backwards moving feedplate
  - Motor is translocated underneath the carriage
- Comfort of a sloped slicer due to the slope of the carriage and the knife
- Solid housing in anodized aluminium
- Carriage, feed plate and protective sickle made of durable light metal and fully anodized
- Air-cooled motor with extremely hushed propulsion
- Blade is made of special steel and guarantees a fine cutting result
- Infinitely variable adjustment of rounds: 0-27 mm
- 4 sucking feet for safe standing
- Hinged carriage for easy cleaning
- Free running roller on carriage in order to achieve silent and low-maintenance operation

### Option

- Teflon-coating of knife

### Technical Specifications

Model	PANIS 250
Art. No.	4013
Blade Ø	250 mm
Cutting area	230 x 190 mm
Power rating	0,30 kW
Dimensions (WxDxH)	440 x 610 x 360 mm
Dead weight	21 kg
Type of current	230 V

Technical modifications might be due to technical improvements.