

# PRODUCT INFORMATION



## Gravity Feed Slicers with automatic Transmission



Automatic



Automatic-Z with counting device

## Gravity Feed Slicers – AUTOMATIC / AUTOMATIC-Z

- Optimal processing due to steeply slope of the carriage and automatic transmission of carriage
  - Automatic operation of the carriage up to 42 movements per minute, also reversible in manual operation
  - Extremely solid, wear-free and fatigue-proofed piezo-electric switch technology for a high number of switching cycles
  - Solid housing in anodized aluminium
  - Carriage with integrated runner, feed plate and protective sickle made of durable light metal and fully anodized
  - Multifunctional blade of the latest generation: 2-level profile and hard-chrome plated surface finish for improved non-stick effect (Teflon blade no longer required for cutting cheese)
  - Infinitely variable adjustment of rounds: 0 – 15 mm
  - Carriage removable without any tools for easy cleaning
  - Separate shaping device to re-sharpen the blade
- Options**
- Unloading device for the knife for save cleaning
  - Cut protection glove
  - Serrated knife for cutting bread
  - Electronic counting device (counting backwards) with self-acting disconnection

Technical Specifications		
Model	Automatic	Automatic-Z
Art. No.	4070	4074
Blade Ø	300 mm	
Cutting area	240 x 220 mm	
Power rating	0.37 kW	
Dimensions (WxDxH)	500 x 700 x 650 mm	
Dead weight	51 kg	
Type of current	400 V	

Technical modifications might be due to technical improvements.