

# PRODUCT INFORMATION



## Bun Cutting & Bread Slicing Machines



Adjustment knobs for easy regulation of the incision depth and height



Effortless top cover removal

## Bun Cutting Machine – BS-H series

- Robust lacquered housing
- All surfaces that come into contact with the product are made of stainless steel
- Circular blade made of special steel with fine teeth for a gentle cut and less crumb formation
- Feed chute adjustable in height and width for different sizes of clippings
- Tool-free adjustment knobs to regulate the horizontal cut-in or average as well as the height of the cut
- The machine cuts bun, baguettes, croissants, etc. quickly and reliably
- Easiest to use: throw bun into the insertion chute and collect them in any collection container below
- The working speed depends on the speed of the operator, so that a output of up to 2000 buns per hour is possible
- Keeping the outer housing clean is sufficient for daily cleaning
- Easy removal of the top cover for occasional general cleaning
- Auto power off for added safety
- Automatic shut-off, intrusion protection and control window made of transparent plexiglass for easy monitoring of the cutting process for more safety

Technical Specifications		
Model	BS-H-230	BS-H-400
Art. No.	4338	4337
Food height	min. 40 / max. 80 mm	
Food width	max. 130 mm	
Cutting height	18-28 mm	
Incision depth	0-15 mm or total	
Dimensions (WxDxH)	400 x 700 x 800 mm	
Power rating / Type of current	0.75 kW / 230 V	0.75 kW / 400 V
Dead weight	38 kg	

Technical modifications might be due to technical improvements.