

Food processing machines



Friction drum
with wide aperture

Grater – Model Gratta

- Perfect grater for cheese, chocolate, dry bread etc. for usage in restaurants, hotels, communal catering, bakeries and caterings
- Aluminium housing
- Friction drum in stainless steel with endless number of sharp grating blades
- Quiet run of friction drum because of Styropor protected drum core
- Motor base with cooling traps in Aluminium with stainless steel lids
- With electronic engine break
- Wide filling shaft with sensor-controlled automatic switchoff
- Drip tray in stainless steel: Ø 200mm, height 80mm

Technical Specifications

Model	Gratta-230
Art. No.	4810
Filling shaft	140 x 80 mm
Capacity	bis zu 70 kg
Dimensions (WxDxH)	420 x 320 x 440 mm
Power rating	0.74 kW
Dead weight	20 kg
Type of current	230 V

Technical modifications might be due to technical improvements.