

# PRODUCT INFORMATION



## Food Processing Machines



Wide filling shaft



VitalisPro with  
Throw-off slide

## Vegetable Cutting Machine – series VITALIS PRO

- Time-saving cutting of vegetables, fruits, and mozzarella
  - Funnel and socket in anodized Aluminium
  - Cover with wide filling shaft (with holding web)
  - Solid bayonet-catch for cover
  - Casing, cap, press lifter, and disc carrying shaft in rust-resistant steel
  - Stamper, presser, and drip tray in highly resistant plastic
  - Highest safety during work and cleaning with sensor-controlled automatic switchoff
  - Easy operations because of two feeding pipes for cutting longish/round (Ø 50mm) or oval (Ø 192mm with holding web) commodities
  - On-/Off-switch – IP54
  - Simple cleaning because of easily removable cover
  - Easy exchange of the plates
  - Extent of delivery without plates
  - Wide range of plates for variable cuttings:  
Slice cuttings (1, 2, 3, 5, 8, 10mm)  
Chopstick cuttings (2,5x2,5, 4x4, 6x6, 8x8, 10x10mm)  
Grating (2, 3, 4, 7, 8, 9mm)  
Rasp knife (Ø 2mm)  
Dicing (8x8, 10x10, 20x20mm)
- Options:**
- Plate rack for 5-6 discs
  - Throw-off slide

### Technical Specifications

Model	VitalisPro-230	VitalisPro-400
Art. No.	4496	4497
Dimensions* (WxDxH)	460 x 592 x 915 mm	
Set-up area	225 x 255 mm	
Power rating	0,51 kW	
Operating speed	300 rpm	
Dead weight	20 kg	
Type of current	230 V	400 V

Technical modifications might be due to technical improvements.