

PRODUCT INFORMATION



Food Processing Machines



Option: With chute to eject for individual collecting boxes



Option: Plate rack for 5-6 discs, plastic-coated



Slicing discs A:
1 / 2 / 3 / 8 / 10 mm
5mm-Sichelmesser



Wave cutting
discs AxW:
2 / 3 mm



Julienne-/Chopstick discs F:
2,5x2,5 / 4x4 / 6x6 /
8x8 / 10x10 mm



Grating discs S:
2 / 3 / 4 / 7 / 8 / 9 mm
Raspings disc 2mm



Dicing discs C:
8x8 / 10x10 / 20x20 mm
(only combined with
slicing discs series A)

Vegetable Cutting Machine – Series VITALIS

- Vegetable cutting machine for time-saving cutting of vegetables, fruits, röstis and mozzarella
 - Funnel and socket are in Aluminium anodized
 - Casing, cap, press lifter, and disc carrying shaft in stainless steel
 - Pestle, press, and receiving tray in highly resistant plastic
 - Highest safety during work and cleaning because of sensor-controlled automatic switch-off
 - Easy operations because of two feeding pipes for cutting English/round (Ø50mm) or oval (155x80mm) commodities
 - On-/Off-switch IP54
 - Easy exchange of the plates
 - Delivery without discs
 - Wide range of plates for variable cuttings
- Optionen**
- Plate rack for 5-6 discs
 - Chute to reject for individual collecting boxes

Technical Specifications		
Model	Vitalis-230	Vitalis-400
Art. No.	4498	4499
Dimensions* (BxTxH)	400 x 510 x 790 mm	
Installation surface	225 x 255 mm	
Revolutions	300 rpm	
Power rating	0.51 kW	
Dead weight	24 kg	
Type of current	230 V	400 V
Technical modifications might be due to technical improvements.		

* With opened press