

PRODUCT INFORMATION

ADE

Meat Processing Machines



Stand Meat Grinder – FLX130-400 model

- Stand grinder with housing made of stainless steel
- Cutter set, worm, cylinder and filler tray in stainless steel
- Large funnel, Ø 115 mm, with hand protection
- Removable filler tray for thorough cleaning
- With coded micro switch
- With 5-piece-Unger-cutting set: pre-cutter, two cutters, two perforated discs (Ø 4,5 mm and 7,8 mm)
- Heavy duty motor with reverse switch
- Optionally with mobile base

Technical Specifications	
Model	FLX130-400
Art. No.	4329
Perforated disks Ø	130 mm
Capacity up to ¹	1,200 kg/h
Dimensions (WxDxH)	400 x 730 x 930 mm
Dead Weight	112 kg
Power rating	5.25 kW
Type of current	400 V

Technical modifications might be due to technical improvements.

¹ Actual capacity depending on the size and quality of the pieces of meat.