

## Food Processing Machines



### Burger Former – Bully1000-230 model

- Automated production of patties, fish cakes or similar products
  - Incl. single forming drum for patties with diameter 130 mm, max. height 32 mm
  - With single forming drum production of up to 1,300 pieces per hour
  - Easy adjustment of the cutting height with the help of an adjustment and locking screw at the forming drum
  - Peraluman castings, other parts stainless steel
  - Cleaning the housing with a water hose (no high pressure!), housing IP65, switch unit IP69
  - Aluminum mixing paddle
  - Continuous movement of the product with the help of the mixing paddle for uniform mixing of the mass to be processed
  - Incl. scraper for the forming drum for cleaning during operation
  - Easy disassembly of mixing paddle, hopper, scraper, conveyor belt, forming drum and accessories for easy cleaning
  - Removable parts are dishwasher safe
  - Magnetic sensors to control the closed lid, the closed protective cap and built-in forming drum for maximum security
  - Hopper volume: 16 Liter
  - Conveyor belt length: 390 mm
- Options:**
- Release film dispenser for separating films size 114 x 114 mm and 135 x 135 mm (not retrofittable)
  - Stainless steel mixing paddle
  - Extended conveyor belt: 900 mm
  - Cleaning wire on the conveyor belt (not retrofittable)
  - Pneumatic scraper (not retrofittable)
  - Foot pedal as a pulse switch for manual operation (not retrofittable)
  - Mobile base frame (not retrofittable)
  - More single, double, triple, and quadruple as well as special forming drums, max. height 32 mm

#### Technical Specifications

Model	Bully1000-230
Art. No.	4352
Dimensions (WxDxH)	518 x 579 x 607 mm
Dead weight	57 kg
Power rating	0.55 kW
Type of current	230 V
Technical modifications might be due to technical improvements.	