



## Burger Former – Bully2000-230 model

- Automated production of patties, fish cakes or similar products
  - Incl. single forming drum for patties with diameter 130 mm, max. height 32 mm
  - Incl. speed controller for the running speed of the conveyor belt
  - With single forming drum production of up to 3,600 pieces per hour
  - Easy adjustment of the cutting height with the help of an adjustment and locking screw at the forming drum
  - Peraluman castings, other stainless steel parts
  - Stainless steel mixing paddle
  - Continuous movement of the product with the help of the mixing paddle for uniform mixing of the mass to be processed
  - Incl. scraper for the forming drum for cleaning during operation
  - Easy disassembly of mixing paddle, hopper, scraper, conveyor belt, forming drum and accessories for easy cleaning
  - Magnetic sensors to control the closed lid, the closed protective cap and built-in forming drum for maximum security
  - Incl. foot pedal as a pulse switch for manual operation
  - Hopper volume: 20 liter
  - Conveyor belt length: 900 mm
  - Release film dispenser for separating films size 135 x 135 mm
- Options:**
- Larger hopper: 40 liter
  - Shortened conveyor belt: 390 mm
  - Pneumatic scraper (not retrofittable)
  - Spread water system (not retrofittable)
  - Mobile base frame (not retrofittable)
  - More single, double, triple, and quadruple as well as special forming drums, max. height 32 mm
  - In combination with ball former model BF as Bully system (only with conveyor belt length 900 mm)

### Technical Specifications

Model	Bully2000-230
Art. No.	4362-01
Dimensions (WxDxH)	637 x 1113 x 629 mm
Dead weight	68 kg
Power rating	0.75 kW
Type of current	230 V

Technical modifications might be due to technical improvements.