



Strip Cutter – Schneidfix-230 model

- Solid housing in anodized aluminum
- Easy operating and cleaning
- With gear transmission
- Ideal for preparing salads and delicacies
- Chops meat, sausage, and cheese
- For meat pieces up to 150 x 20 mm, standard with a strip width of 4 mm, optionally with 8 or 13 mm
- Includes knife roller with blades and pressure roller made of stainless steel, standard with a strip width of 4 mm
- Easy conversion between strip cutter and meat tenderizer possible (separate Steakonom insert consisting of two tenderizing rollers and a special comb set required)

Option

- Schneidfix insert for strip width of 8 mm and 13 mm

Technical Specifications	
Model	Schneidfix-230
Art. No.	3405
Dimensions (WxDxH)	440 x 220 x 465 mm
Power rating	0.18 kW
Max. width of meat	150 mm
Max. thickness of meat	20 mm
Dead weight	16 kg
Type of current	230 V
Technical modifications might be due to technical improvements.	