

PRODUCT INFORMATION



Gravity Feed Slicers with automatic Transmission



Robust piezo switch



Easy switch from automatic to manual operation

Automatic Gravity Feed Slicer – AUTOMATIC300-400

- Solid housing and carriage in anodized aluminum
- Automatic operation of the carriage up to 42 movements per minute, also reversible in manual operation
- Shift lever for easy switch from automatic to manual operation
- Optimal processing due to steeply slope of the carriage and automatic transmission of carriage
- Includes guide rail for product fixation
- 3-way adjustable end piece holder for various cutting materials
- Powerful motor
- Blade drive via gear transmission
- Multifunctional blade of the latest generation: 2-level profile with hard-chrome plated surface finish for improved non-stick effect (Teflon knife for cutting cheese no longer required)
- Continuously adjustable slice thickness: 0-15 mm
- Removable carriage for effortless cleaning
- Suitable for intended continuous operation
- Delivery includes a sharpening tool

Options

- Blade removal device
- Cut resistant glove
- Also available with a counter with automatic shut-off as the Automatic300-Z-400 model

Technical Specifications

Model	Automatic300-400
Art. No.	4070
Blade Ø	300 mm
Cutting area	240 x 220 mm
Power rating	0.37 kW
Dimensions (WxDxH)	500 x 700 x 650 mm
Dead weight	51 kg
Type of current	400 V

Technical modifications might be due to technical improvements.