

PRODUCT INFORMATION



Gravity Feed Slicers with automatic Transmission



Zählwerk mit automatischer Abschaltung



Robust piezo switch



Easy switch from automatic to manual operation

Automatic Gravity Feed Slicer – AUTOMATIC300-Z-400

- Solid housing and carriage in anodized aluminum
- Automatic operation of the carriage up to 42 movements per minute, also reversible in manual operation
- Shift lever for easy switch from automatic to manual operation
- Automatic shutdown after the preset number of carriage strokes
- Optimal processing due to steeply slope of the carriage and automatic transmission of carriage
- Includes guide rail for product fixation
- 3-way adjustable end piece holder for various cutting materials
- Powerful motor
- Blade drive via gear transmission
- Multifunctional blade of the latest generation: 2-level profile with hard-chrome plated surface finish for improved non-stick effect (Teflon knife for cutting cheese no longer required)
- Continuously adjustable slice thickness: 0-15 mm
- Removable carriage for effortless cleaning
- Suitable for intended continuous operation
- Delivery includes a sharpening tool

Options

- Blade removal device
- Cut resistant glove

Technical Specifications

Model	Automatic300-Z-400
Art. No.	4074
Blade Ø	300 mm
Cutting area	240 x 220 mm
Power rating	0.37 kW
Dimensions (WxDxH)	600 x 745 x 680 mm
Dead weight	51 kg
Type of current	400 V

Technical modifications might be due to technical improvements.