

PRODUCT INFORMATION

ADE

Gravity Feed Slicers



Standard with Teflon coating on the stop plate and blade cover plate

Slightly sloped - Series VICTORIA TSM

- Wide space for cleaning due to prolonged knife hub and underneath of the knife sickle
- Solid housing, carriage, feed plate and protective sickle made of durable anodized aluminium
- Air-cooled motor with extremely hushed propulsion
- Multifunctional blade of the latest generation: 2-level profile and hard-chrome plated surface finish for improved non-stick effect (Teflon blade no longer required for cutting cheese)
- Infinitely variable adjustment of rounds: 0–15 mm
- Four sucking feet for safe standing
- Comfort of a sloped slicer due to the slope of the carriage and the knife
- Easy removable carriage and Teflon coating on the stop plate and blade cover plate for easy cleaning
- Separate shaping device to re-sharpen the blade

Options

- Unloading device for the knife for save purgation
- Cut protection glove
- Serrated knife for cutting bread

Technical Specifications

Model	Victoria250TSM-230	Victoria300TSM-230
Art. No.	4053	4054
Knife Ø	250 mm	300 mm
Cutting area	180 x 160 mm	215 x 180 mm
Power rating	0.23 kW	0.23 kW
Dim. (WxDxH)	440 x 530 x 360 mm	480 x 600 x 390 mm
Dead weight	19 kg	22 kg
Type of current	230 V	230 V

Technical modifications might be due to technical improvements.