



Burger Former – Bully1000-230 model

- Automated production of patties, fish cakes or similar products
 - Incl. single forming drum for patties with diameter 130 mm, max. height 32 mm
 - With single forming drum production of up to 1,300 pieces per hour
 - Easy adjustment of the cutting height with the help of an adjustment and locking screw at the forming drum
 - Peraluman castings, other stainless steel parts
 - Aluminum mixing paddle
 - Continuous movement of the product with the help of the mixing paddle for uniform mixing of the mass to be processed
 - Incl. scraper for the forming drum for cleaning during operation
 - Easy disassembly of mixing paddle, hopper, scraper, conveyor belt, forming drum and accessories for easy cleaning
 - Magnetic sensors to control the closed lid, the closed protective cap and built-in forming drum for maximum security
 - Hopper volume: 16 Liter
 - Conveyor belt length: 390 mm
- Options:**
- Release film dispenser for separating films size 114 x 114 mm and 135 x 135 mm (not retrofittable)
 - Stainless steel mixing paddle
 - Extended conveyor belt: 900 mm
 - Pneumatic scraper (not retrofittable)
 - Foot pedal as a pulse switch for manual operation (not retrofittable)
 - Mobile base frame (not retrofittable)
 - More single, double, triple, and quadruple as well as special forming drums, max. height 32 mm

| Technical Specifications | |
|---|--------------------|
| Model | Bully1000-230 |
| Art. No. | 4352 |
| Dimensions (WxDxH) | 518 x 579 x 607 mm |
| Dead weight | 57 kg |
| Power rating | 0.55 kW |
| Type of current | 230 V |
| Technical modifications might be due to technical improvements. | |