

# PRODUCT INFORMATION

# ADE

## Straight Feed Slicers



Standard with Teflon coating on the stop plate and blade cover plate

## Straight Feed Slicer – Series VICTORIA TSM-V

- Wide space for cleaning due to prolonged knife hub and underneath of the knife sickle
- Solid housing, carriage, feed plate and protective sickle made of durable anodized aluminium
- Air-cooled motor with extremely hushed propulsion
- Multifunctional blade of the latest generation: 2-level profile and hard-chrome plated surface finish for improved non-stick effect (Teflon blade no longer required for cutting cheese)
- Infinitely variable adjustment of rounds: 0–15 mm
- Four sucking feet for safe standing
- Easy removable carriage and Teflon coating on the stop plate and blade cover plate for easy cleaning
- Separate sharpening device to re-sharpen the blade

### Options

- Unloading device for the knife for save purgation
- Cut protection glove
- Teflon-coating, e. g. for cutting cheese
- Serrated knife for cutting bread

### Technical Specifications

	Victoria250TSM-V	Victoria300TSM-V
Model	Victoria250TSM-V	Victoria300TSM-V
Art. No.	4028	4029
Blade Ø	250 mm	300 mm
Cutting area	180 x 175 mm	215 x 205 mm
Power rating	0,23 kW	0,23 kW
Dim. (WxDxH)	460 x 440 x 390 mm	520 x 610 x 440 mm
Dead weight	20 kg	23 kg
Type of current	230 V	230 V

Technical modifications might be due to technical improvements.