

PRODUCT INFORMATION



Gravity Feed Slicers



Hinged carriage

Slightly sloped slicer – Model Snack220

- Slightly sloped slicer with lacquered cast Aluminium base
 - Blade cover, tray and bulkhead in anodized aluminium
 - Air-cooled motor with extremely hushed propulsion
 - Multifunctional blade of the latest generation: 2-level profile and hard-chrome plated surface finish for improved non-stick effect (Teflon blade no longer required for cutting cheese)
 - Infinitely variable adjustment: 0-14 mm
 - Four suction feet for safe standing
 - Hinged carriage for easy cleaning
 - Blade sharpener included
- Options:
- Cut protection gloves

Technical Specifications

Model	Snack220
Art. No.	4012
Blade Ø	220 mm
Cutting area (DxH)	210 x 145 mm
Dimensions (WxDxH)	530 x 480 x 320 mm
Dead weight	12.5 kg
Power rating	0.14 kW
Type of current	230 V

Technical modifications might be due to technical improvements.