

# PRODUCT INFORMATION

# ADE

## Gravity Feed Slicers



## Slightly sloped - Series VICTORIA

- Wide space for cleaning due to prolonged knife hub and underneath of the knife sickle
- Solid housing, carriage, feed plate and protective sickle made of durable anodized aluminium
- Air-cooled motor with extremely hushed propulsion
- Multifunctional blade of the latest generation: 2-level profile and hard-chrome plated surface finish for improved non-stick effect (Teflon blade no longer required for cutting cheese)
- Infinitely variable adjustment of rounds: 0–15 mm
- Four sucking feet for safe standing
- Comfort of a sloped slicer due to the slope of the carriage and the knife
- Carriage removable without any tools for easy cleaning
- Separate shaping device to re-sharpen the blade

### Options

- Unloading device for the knife for save purgation
- Cut protection glove
- Serrated knife for cutting bread

### Technical Specifications

|                 | Victoria250-230    | Victoria300-230    |
|-----------------|--------------------|--------------------|
| Model           | Victoria250-230    | Victoria300-230    |
| Art. No.        | 4086               | 4088               |
| Knife Ø         | 250 mm             | 300 mm             |
| Cutting area    | 180 x 160 mm       | 215 x 180 mm       |
| Power rating    | 0.23 kW            | 0.23 kW            |
| Dim. (WxDxH)    | 440 x 530 x 360 mm | 480 x 600 x 390 mm |
| Dead weight     | 19 kg              | 22 kg              |
| Type of current | 230 V              | 230 V              |

Technical modifications might be due to technical improvements.