

PRODUCT INFORMATION



Electronic Industrial Scales



Weighing platform and underframe
in high-quality stainless steel

Platform scale – Series VSL-Niro+STAN07 (approved available)

- Weighing platform and underframe made of high-quality stainless steel
 - Stainless steel load cell IP65
 - Overload protection
 - Height-adjustable leveling feet
 - Mounted with indicator in stainless steel housing IP65
 - Large, 5-colour LCD-Display with six digits with backlight, height of digits 25 mm
 - RS232-interface
 - Functions: Weighing, Tare, Counting, Summarizing, Check Weighing – free programmable maximum values with optical and acoustical indication
 - Lights function: programmable change of colour of backlight in dependence of goal attainment
 - Each 100 product memory at check-weighing, piece counting and quantity memory for piece counting
 - Integrated power supply by mains (100-240V/50-60Hz; integrated PSU, cable length 2m)
 - Indicator for mounting on the wall or set up on a table (incl. wall mount)
- Optional:**
- Rechargeable battery with Lithium-Polymer accumulator with approx. 250 working hours

Note: If approved version (models –e) is needed, please order approval with the scale.

Later approval isn't possible!

For CE approval outside Germany, please be sure to provide the postal code of the installation location.

Technical Specifications

Model	Art.-No.	Weighing platform (mm)	Capacity	Graduation (CE approved / non approved)	Dead Weight
VSL-Niro1-15+STAN07	1230-15	300 x 240 x 110	15 kg	5 g / 1 g	12 kg
VSL-Niro3-30+STAN07	1231-30	500 x 400 x 150	30 kg	10 g / 1 g	22 kg
VSL-Niro3-60+STAN07	1231-60	500 x 400 x 150	60 kg	20 g / 2 g	22 kg
VSL-Niro3-150+STAN07	1231-150	500 x 500 x 150	150 kg	50 g / 5 g	22 kg

Technical modifications might be due to further developments.